

## Bulletin 592 E1 Plus Solid-State Overload Relays

### Bulletin 592-EE – Three Phase Devices

- Selectable Trip Class (10, 15, 20, 30)
- Selectable Manual/Auto-Manual Reset

| Mounts to Contactor | Adjustment Range [A] | Cat. No. |
|---------------------|----------------------|----------|
| 00                  | 0,1 a 0,5            | 592-EEAT |
|                     | 0.2...1.0            | 592-EEBT |
|                     | 1.0...5.0            | 592-EECT |
|                     | 3.2...16             | 592-EEDT |
| 0...2               | 0.2...1.0            | 592-EEBC |
|                     | 1.0...5.0            | 592-EECC |
|                     | 3.2...16             | 592-EEDC |
|                     | 5.4...27             | 592-EEEC |
|                     | 6.0...45             | 592-EEFC |
| 3                   | 9...45               | 592-EEFD |
|                     | 18...90              | 592-EEGD |
| 4                   | 30...150             | 592-EEHE |
| 5                   | 60...300             | 592-EEKF |
| 6                   | 120...600            | 592-EEMG |

### Bulletin 592S-EE – Single-Phase Devices

- Selectable Trip Class (10, 15, 20, 30)
- Selectable Manual/Auto-Manual Reset

| Mounts to Contactor | Adjustment Range [A] | Cat. No.  |
|---------------------|----------------------|-----------|
| 00                  | 1,0 a 5,0            | 592S-EEPT |
|                     | 3.2...16             | 592S-EERT |
|                     | 5,4 a 27             | 592S-EEST |
| 0...2               | 1.0...5.0            | 592S-EEPC |
|                     | 3.2...16             | 592S-EERC |
|                     | 5.4...27             | 592S-EESC |
|                     | 9...45               | 592S-EETC |
| 3                   | 18...90              | 592S-EEUD |