















Bulletin 855E 50 Mm Control Tower™ Stack Lights

	Description	Cat. No.	
	Incandescent Lamps	855T-L12	
	12V AC/DC		
	24V AC/DC	855T-L24	
	(BA15d Bayonet) 19 mm Socket Height	120V AC	855T-L10
	240V AC	855T-L20	
	LED Lamps for Socket-Mounted Modules	Color	Cat. No.
	12V AC/DC	Red	855E-LL12R
		Green	855E-LL12G
		Amber	855E-LL12A
		Blue	855E-LL12B
		Yellow	855E-LL12Y
		White*	855E-LL12W
	24V AC/DC	Red	855E-LL24R
		Green	855E-LL24G
		Amber	855E-LL24A
		Blue	855E-LL24B
		Yellow	855E-LL24Y
		White*	855E-LL24W
	120V AC	Red	855E-LL10R
		Green	855E-LL10G
		Amber	855E-LL10A
		Blue	855E-LL10B
		Yellow	855E-LL10Y
		White*	855E-LL10W
	240V AC	Red	855E-LL20R
Green		855E-LL20G	
Amber		855E-LL20A	
Blue		855E-LL20B	
Yellow		855E-LL20Y	
	White*	855E-LL20W	
	Caps (top of stack)	Color	Cat. No.
	The cap is installed to the top of the uppermost light module. No cap is needed if the top module is a sound module, or a light/with sound module.	Black	855E-ABCAP
		Grey	855E-AGCAP
	Module Securing Screws (Bag of 5)	855E-ASC	
	Gaskets	855E-ALSG	
	Lens O-Ring Seal Replacement rubber O-rings are to be installed between all bases, light, sound, and light/with sound modules. (Package quantity = 5)		
	Surface Mount Gasket	855E-ASFG	
	Replacement flat gasket is to be placed between the mounting surface and the surface mount base. (Package quantity = 5)		
	Pole Foot Gasket	855T-APFG	
	Replacement flat gasket is to be placed between the mounting surface and the pole base bottom foot. (Must order multiples of 5.) For use with Cat. No. 855T-BPM10C and 855T-BPM25C pole bases, Cat. No. 854JIBSFC and 854J-BSFQD5C bases, and Bul. 855T, 855E, 855F, 855D, 854J, and 854K quick release bases.		

* White LED lamps are to be used with a lens option of Clear.

	Description	Cat. No.
	Gaskets	
	Vertical Mount Gasket Replacement flat gasket is to be placed between the mounting surface and the vertical mount base (Cat. No. 854J-BVMC).(Package quantity = 5)	855T-AVFG
	Tube Mount Gasket Replacement O-ring gasket is to be placed in the tube mount pole opening before the tube is installed (BTM- and GTM- type bases).(Package quantity = 5)	855T-AVTG
	Mounting Screw Washer Kit Replacement flat washers are used to provide a seal where the mounting screw meets the pole base. (1 kit includes 20 pieces)(Package quantity = 20)	855T-AMSG
	Pole Connection Boxes	Cat. No.
	Black surface mount with PG16 threaded side entrance	855T-BSMP
	Black surface mount with M20 threaded side entrance	855T-BSMR
	Black vertical mount with PG16 threaded side entrance	855T-BVMP
	Black vertical mount with M20 threaded side entrance	855T-BVMR
	Black magnetic mount with PG16 threaded side entrance	855T-BMMP
	Black magnetic mount with M20 threaded side entrance	855T-BMMR
	Black magnetic mount with 1/2 in. NPT threaded side entrance	855T-BMMN
	Black PG16 threaded hole plug	855T-ABUP
	Black M20 threaded hole plug	855T-ABUR
	Black PG16 threaded cable gland	855T-ABCP
	Black M20 threaded cable gland	855T-ABCR
	Black 1/2 in. NPT sealing connector	855T-ABHN
	Mounting Screws (M5 x 40 screws) for mounting Pole Mount Base to Pole Connection Box	855T-AJBS